



INSTALLATION INSTRUCTIONS

Finish Trim Kit #864 for
#173, 240, 275, 299, 310, and 326 Enclosures

PARTS INCLUDED



#1 Finish Material

PARTS SOLD SEPARATELY



Part# 861 (1) can of high temperature adhesive

TOOLS AND SUPPLIES NEEDED

- Utility Knife

INSTALLATION

NOTE: Due to the many variations in enclosure sizes/shapes, the actual parts in the trim kit may be a different size or shape.

1. Measure and cut the #1 Finish Material to size and shape by either using a tape measure or by laying the material over the enclosure and marking the outline.
2. Apply adhesive to the enclosure and/or finish material and affix it to the drawer enclosure. It generally works the best to do small sections at a time.

Call (800) 348-8339 for Technical Support